

Diaphragm Seals

DS/PI-45A

VACUUM GAUGE/DIAPHRAGM SEAL ASSEMBLY

The indication limit for Bourdon tube vacuum gauges attached to diaphragm seals is 25" Hg vacuum.

The above is based on:

1. The use of a dry pressure system free from any liquid, such as water.
2. The use of a proper evacuation (at 200 microns) and fill procedure.
3. The use of a properly deaerated fill. (Deaerate fill at 200 microns until no bubbling occurs while fluid is agitated.)

On line connected assemblies, to eliminate the effect of head pressure, the diaphragm must be in a horizontal line with the center of the gauge and the connecting line must not extend above the horizontal line.